

**Notices SAV : 180310 (26130014) GROUPE 17V**

Eclate	Repère	Code	Description
17	4	26149912	VOLANT FON.15L-17-18-20-27V/KV
17	7	27149730	FLASQ.SUP.VILB.17/20/27VKV-35W
17	8	26149246	RENIFL.16/17/18/20/27V/KV-35WM
17	9	26148180	JT FLASQUE 16/17/18/20V-27V/KV
17	10	26148580	JOINT SPI 16/17/18/20V/27V-KV
17	11	26149542	ROUL.AV.15L-16 A 20V-27VKV-35W
17	12	26140650	VILEBREQUIN 17V-20V-27V
17	13		CARTER
17	14		BOUCHON DE VIDANGE
17	15	26149212	VOY.NIV.HUILE+JT 15L-16/17/20V
17	20	26149544	ROUL AR.15L-16/18-27V/KV-AV40V
17	23	26140102	BIELLE 16V-17V-20V
17	24	26149242	BOUCH.REMPL.16-17-20-27VKV-35W
17	25	26143142	PISTON 16V-17V
17	28	26144142	JEU SEGMENTS 16V-17V
17	31	26148280	JT CARTER HUILE 17-27V/KV-35W
17	33	26139036	CYLINDRE M8 17V
17	35	26141186	PL.CL.15L-16 A 27V/KV-35W-34HP
17	36	27141102	JEU LAMELLES 27V (57*11*0.3)
17	36	27141104	JEU LAMELLES 27V (53*9.5*0.3)
17	38	26149306	CULASSE Ø8 16V-17V-20V-40WB HP
17	39		VIS DE CULASSE
17	40	26142114	FILT.15/22L-16V-26VC-27V/KV-35
17	42	26142322	CART.15/22L-16V-26V-27V/KV-35W
17	46		ECROU DE SORTIE
17	47	26149042	RADIATEUR 16/17/18/20V-35W
17	48	26149810	COUDE SORTIE 15L-16-27V/KV-35W
17	#	26340062	POCHETTE JOINTS 17V
17	#	77261707	KIT JT CULASSE Ø8 NM
17	34	26148257	JT SUP CYLINDRE M8 INTERFACE
17	37	26148006	JOINT CULASSE Ø8 INTERFACE
17	45	26149820	T SORTIE CULASSE 16/18V/27V-KV

Schéma n° 17 GROUPE 17V

