



Perceuse Visseuse à Percussion **BHP343**



| Item | Parts_No. | Parts_Description | Qty | Unit |
|-------|-----------|----------------------------|-----|------|
| 1 | 125310-5 | SPEED CHANGE LEVER ASS'Y | 1 | PC. |
| 1 | 231433-0 | COMPRESSION SPRING 4 | 2 | PC. |
| 2 | 188616-2 | HOUSING SET | 1 | SET |
| 2 | | INC. 14 | 0 | |
| 3 | 865437-6 | BHP343 NAME PLATE | 1 | PC. |
| 3 | 263005-3 | RUBBER PIN 6 | 2 | PC. |
| 4 | 266130-9 | TAPPING SCREW BIND PT 3X16 | 9 | PC. |
| 5 | 232182-2 | LEAF SPRING | 1 | PC. |
| 6 | 419250-0 | F/R CHANGE LEVER | 1 | PC. |
| 7 | 650605-2 | SWITCH TG563FSB-5 | 1 | PC. |
| 8 | 643828-9 | TERMINAL | 1 | PC. |
| 9 | 251468-5 | - FLAT HEAD SCREW M6X22 | 1 | PC. |
| 10 | 766003-1 | KEYLESS DRILL CHUCK 10 | 1 | PC. |
| 11 | 125484-2 | GEAR ASS'Y | 1 | PC. |
| 12 | 629823-3 | DC MOTOR | 1 | PC. |
| 13 | 911003-8 | PAN HEAD SCREW M3X6 | 2 | PC. |
| 14 | 188616-2 | HOUSING SET | 1 | SET |
| 14 | 263005-3 | RUBBER PIN 6 | 2 | PC. |
| 14 | | INC. 2 | 0 | |
| 15 | 424026-2 | CUSHION | 1 | PC. |
| A01 | 784636-0 | + - BIT 2-65 | 1 | PC. |
| A02 | ***DC18RA | DC18RA FAST CHARGER | 1 | PC. |
| A03 | 194065-3 | BATTERY BL1430 SET | 2 | PC. |
| A03 | 194558-0 | BATTERY BL1415 SET | 2 | PC. |
| A03-1 | 194065-3 | BATTERY BL1430 SET | 2 | PC. |
| A04 | 450128-8 | BATTERY COVER | 1 | PC. |
| A05 | 824862-0 | PLASTIC CARRYING CASE | 1 | PC. |
| A05 | 163455-1 | LATCH | 2 | PC. |
| A05 | 419360-3 | HANDLE | 1 | PC. |
| A05A | 824862-0 | PLASTIC CARRYING CASE | 1 | PC. |
| A05A | 163455-1 | LATCH | 2 | PC. |
| A05A | 419360-3 | HANDLE | 1 | PC. |